



Dry Pak Industries, Inc. 116055 Ventura Blvd., Suite 725 | Encino, CA 91436

Tel: (818) 981-7460 | Toll Free: (877) 4-DRYPAK | Fax:(818) 981-7463

WARM MARK TIME TEMPERATURE LABELS

ADHESIVE-BACKED TAG RECORDS WARMING TEMPERATURES FOR SHIPPING AND STORAGE

- MONITORS TEMPERATURE FROM 8 TO 48 HOURS, DEPENDING ON MODEL
- RED COLORING INDICATES EXPOSURE TO WARMER-THAN-ACCEPTABLE CONDITIONS
- AVAILABLE IN A VARIETY OF RESPONSE TEMPERATURES RANGING FROM -18C (0F) TO 37C (99F)
- ACCURACY +/- 1C
- DIMENSIONS: 1.81" X 0.75" X 0.06" (Length x Width x Thickness)

WarmMark Time Temp Tags are a convenient, accurate tool for monitoring temperature during shipping and storage of drug and medical products, vaccines, blood, plasma, diagnostics, gelatin capsule products, chemicals, paint, and temperature sensitive food products.

Response temperatures and run-out times (length of exposure time to a certain temperature) vary with each WarmMark model.

The red coloring indicates exposure to temperatures above the rated temperature for that tag. Color movement through the windows indicates passage of time. If the temperature cools below the threshold, the color stops moving.

WarmMark™ Short Run	Run-Out Times		
	<i>Brief</i>	<i>Moderate</i>	<i>Prolonged</i>
-18°C / 0°F	1 hour	3 hours	12 hours
0°C / 32°F 8°C / 46°F 10°C / 50°F 20°C / 68°F	2 hours	12 hours	48 hours
5°C / 41°F 25°C / 77°F 30°C / 86°F 37°C / 99°F	30 minutes	2 hours	8 hours

